



932 000 059 \*\*

932 061 002 \*\*

211 000 010 00

100 200 100 00

932 063 002 \*\*

<del>+10</del> +12 <del>+13</del>

+22

**+33** +41

+75 +76 **78** 

● +80

932 000 067 \*\*

932 000 066 \*\*

100 000 007 \*\*



932 063 001 \*\*



100.000.800.00



932 000 068 75

Tel: +49 (0) 95 68 / 856-142 Fax: +49 (0) 95 68 / 856-183 e-mail: service@rollytoys.de


932 000 065 75

932 061 001 \*\* - 100 000 042 80

300 000 022 \*\*













## **WARNING:**

**CHOKING HAZARD - Small parts.** Not for children under 3 years.

- CHOKING HAZARD: Small parts. Danger of being swallowed. Contains small parts in non assembled state. Must be assembled by adults.
- Adult supervision required.
- Never use near steps, slopes, driveways, hills, roadways, alleys or swimming pool areas.
- Always wear shoes.
- Never allow more than one rider.
- The use of protective gear and a safety helmet is highly recommended.
- Conforms to the requirements of **ASTM Standard Consumer Safety** Specification on Toy Safety, F 963
- Not suitable for children under 3 years.

---NORTH & SOUTH AMERICA only---

ndays warranty

From the date of purchase + guaranteed spare part service

The warranty does not cover dammages caused by improper use or neglect



in

Germany



300 000 005 80



G



100 010 020 80



100 000 075 78

100 000 013 99









Franz Schneider GmbH & Co KG P.O.Box 1460 D-96459 · Neustadt bei Coburg · Germany

Tel.: +49 (0) 95 68 / 856-0 Fax.: +49 (0) 95 68 / 856-190 www.rollvtovs.com

